
12. Januar 2021 · 04 · Technische Änderungen vorbehalten.

Wärmemengenzähler-Set waagerecht Heat Meter Set, horizontal



Montageanleitung/Assembly instruction



Das Roth Wärmemengenzähler Einbauset waagerecht kann mit dem Roth Heizkreisverteiler Universal oder mit Durchflussanzeige eingesetzt werden.

Das Wärmemengenzähler-Set wird wie oben abgebildet montiert:

Der Volumenmesser wird in der Rücklauf-Leitung zum Heizkreisverteiler (A) montiert.

Der direkt eintauchender Temperaturfühler mit M10x1 Gewinde wird in die Fühleraufnahme des Kugelhahns (B) im Vorlauf montiert.

Montageraum: 250 mm x 268 mm. Wichtig: UP-Verteilerschrank auf min. 120 mm ausziehen, Abmessung Wärmemengenzähler beachten. The "Roth Heat Meter Set, horizontal" can be deployed in combination with a Roth Universal heating circuit manifold or Roth manifold with flow meter.

The Heat Meter Set is mounted shown on the picture above:

The volume meter is positioned in the return of the manifold (A).

Installing the temperature sensor M10x1 with direct contact to the liquid, using ball valve (B) in supply.

Assembly area: 250 mm x 268 mm.

The front of the manifold cabinet should be pulled out to min.120 mm, please observe the heat meter dimension.